



# VALTRA



## N122, N142 Versu + Direct

Leikkaa tankin asennuskehikon etukiinnike (B) irti ja hitsaa sen tilalle JAKEn toimittama kiinnike (A).

Cut off the original front fastener (B) from the mounting frame of the tank and weld on its place the fastener (A) delivered by JAKE.

